











SF-2200 STRINGER MOUNT










PARTS LIST

IF ANY PIECES ARE MISSING, PLEASE CONTACT US IMMEDIATELY:
HELLO@SYNERGEEFITNESS.COM OR 1.855.217.7136

1.  LEFT-SIDE STRINGER	2.  MIDDLE STRINGER	3.  RIGHT-SIDE STRINGER	4.  BACK CONNECTOR	5.  M10 NYLON LOCK-NUT
6.  M8 NYLON LOCKNUT	7.  M8 WASHER	8.  M10 WASHER	9.  M10X25 STEEL HEX HEAD SCREW	10.  M8X20 STEEL HEX HEAD SCREW
11.  M10X80 STEEL SCREW				

HARDWARE SIZING CHART


M8X20 STEEL HEX HEAD		QTY 16	IN STEPS 2A-B
M10X25 STEEL HEX HEAD		QTY 8	IN STEPS 1
M10X80 STEEL SCREW		QTY 16	IN STEPS 5
M10 NYLON LOCKNUT		QTY 8	IN STEPS 1
M8 NYLON LOCKNUT		QTY 16	IN STEPS 2A-B
M10 WASHER		QTY 32	IN STEPS 1-5
M8 WASHER		QTY 32	IN STEPS 1-5

ASSEMBLY

STEP: 1

STEP PART GUIDE

#	PART NAME	QTY
1.	LEFT-SIDE STRINGER	1
2.	MIDDLE STRINGER	1
3.	RIGHT-SIDE STRINGER	1
4.	BACK CONNECTOR	1
6.	M8 NUT	8
7.	M8 WASHER	16
10.	M8x25 STEEL HEX HEAD SCREW	8




ASSEMBLY

STEP: 2A

WALL RACK MOUNT

STEP PART GUIDE

#	PART NAME	QTY
5.	M10 NUT	4
8.	M10 WASHER	8
9.	M10x25 STEEL HEX HEAD SCREW	4




ASSEMBLY

STEP: 2B

FOLDING RACK MOUNT

STEP PART GUIDE


#	PART NAME	QTY
5.	M10 NUT	4
8.	M10 WASHER	8
9.	M10x25 STEEL HEX HEAD SCREW	4



ASSEMBLY

STEP: 3

- ENSURE STRINGER IS FLAT ON WALL
- ENSURE UPRIGHT FEET ARE FLAT ON THE GROUND
- ENSURE UPRIGHTS ARE PARALLEL WITH EACH OTHER



ASSEMBLY


STEP: 4

- LINE UP RACK WITH STUD SPACING

STEP PART GUIDE

#	PART NAME	QTY
7.	M10 WASHER	8
11.	M10x80 STEEL SCREW	8

16" STUD SPACING



24" STUD SPACING

