




# WEIGHTED BAR RACK




# PARTS LIST

| KEY | PART                             | QTY |
|-----|----------------------------------|-----|
| 1   | BOTTOM FRAME UPRIGHT             | 2   |
| 2   | TOP FRAME UPRIGHT                | 2   |
| 3   | SIDE FRAMES                      | 2   |
| 4   | BOTTOM FRONT DIVIDER             | 1   |
| 5   | TOP BAR DIVIDER                  | 1   |
| 6   | FLOOR PIECE                      | 1   |
| 7   | M8X15 SET (Bolt and washer)      | 6   |
| 8   | M8x80 SET (BOLT, WASHER X2, NUT) | 4   |
| 9   | M8X50 BOLT                       | 12  |
| 10  | M8 WASHER                        | 20  |
| 11  | M8 NUT                           | 8   |
| 12  | DIVIDER POLES                    | 3   |
| 13  | BACK BOTTOM DIVIDER              | 1   |



**IF ANY PIECES ARE MISSING, PLEASE CONTACT US IMMEDIATELY:  
HELLO@SYNERGEEFITNESS.COM OR 1.855.217.7136**

**1.**




Insert the top uprights into the bottom uprights and secure with the M8X15 Bolts and washers.

# 2.



Assemble the bottom bar holder with the divider poles sitting the front and back bottom dividers. Align the two side frames with the floor piece and the bottom bar divider in between. Once aligned tightened as shown above.

# 3.



Align the bottom piece created in step 2 and attach it to the upright. Align the top bar divider inside of the two uprights and secure.